






**Explanation of marking required by EN 13743*
on the disc or the packaging, and on the back-up pad**

Declaration of conformity on the disc and the back-up pad: EN 13743
Restriction of use:  Use with a back-up pad
Maximum rotational frequency indicated in rotation per minute [rpm]
Maximum operating speed indicated in meter per second [m/s]
Name of manufacturer, supplier, importer, or registered trademark
Safety pictograms (PPE)    
Dimensions indicated in millimetres [mm]
Specification mark (optional)

* EN 13743 marking shows that the producer has followed the essential safety requirements of the European safety standard for fibre discs in order to reduce the risks for end-users.

IMPORTANT NOTICE

Every effort has been made to ensure that all information supplied in this leaflet is accurate and up to date. We cannot accept, however, responsibility for any error or omission, nor for any consequential loss or damage so arising (E & OE).

© FEPA 2018

Endorsed by:




PASS ON THIS LEAFLET TO THOSE USING GRINDING DISCS

The recommendations contained in this leaflet should be followed by all users of abrasive products in the interests of their personal safety

GENERAL PRINCIPLES OF SAFETY

Abrasive discs improperly used can be very dangerous. This leaflet covers the use of coated abrasive fibre discs on angle grinders.




Read the machine
handbook


Discs used for grinding (examples)



Plain bore




Slotted bore




Shaped
peripheries

Guards recommended for grinding



























For 180 & 230 mm
diameter discs























For discs < 180 mm diameter

Back-up pad used with fibre discs



1	 <p>DO'S</p>  <p>EN 13743</p> <p>Ensure the disc or the packaging bears the mark EN 13743</p>	<p>DON'TS</p>  <p>Do not use a disc without the EN 13743 mark on it or on its packaging</p>
2	  <p>Always read the safety instructions</p>	  <p>Don't throw away the instructions before reading</p>
3	  <p>Examine the disc for damage or unusual stains</p>	  <p>Never use a damaged disc</p>
4	  <p>12250 rpm 80m/s</p>  <p>12250 rpm 80m/s</p> <p>Check that the speed marked on the machine & the back-up pad is not greater than the speed of the disc</p>	  <p>13300 rpm 13300 rpm</p> <p>Do not use the disc if the speed is lower than the speed marked on the machine, or if no speed is marked on it</p>
5	  <p>Always use with a back-up pad</p>	  <p>Never use without a back-up pad</p>
6	  <p>Align the special nut correctly</p>	  <p>Special nut incorrectly aligned</p>

7	  <p>Ensure the guard is fitted</p>	<p>DON'TS</p>   <p>Never remove the guard</p>
8	  <p>Ensure work piece is secure</p>	  <p>Never grind an unstable work piece</p>
9	  <p>Use protective equipment</p>	  <p>Never grind without protective equipment</p>
10	  <p>Only use for grinding - 10° angle</p>	  <p>Do not use for cutting</p>
11	  <p>Work from side to side without excessive force</p>	  <p>Never force on the disc</p>